




Canon Powershot ELPH 100 HS Battery Replacement

Replace your dying battery to bring the camera back to life.

Written By: Lillia



INTRODUCTION

If your battery light has turned on for your camera, it is dying, and will need a new one, use this guide to help with replacing the battery. This is a very simple procedure, so you have nothing to worry about.



PARTS:

- [Canon Powershot ELPH Battery](#) (1)

If battery is not damaged, it can just be charged with the Canon camera battery charger. If it is damaged, you can purchase a new part from Amazon


Step 1 — Battery



- Locate the battery cover on the bottom of your camera.
- Slide the tab to the right to open the battery cover.

Step 2



- Flip the battery cover open.
 - Using your fingers, slide the battery out of the camera.
-  This was not the original battery that came the camera, so yours may look different.

To reassemble your device, follow these instructions in reverse order.

